

3D PRINTING AND DESIGN REFERENCE DOCUMENT

Document Title:	K1/K1C/K1 MAX extruder current reduction
Document No.:	1718617377
Author(s):	jattie
Contributor(s):	

REVISION HISTORY

Revision	Details of Modification(s)	Reason for modification	Date	By
0	Draft release	How to reduce extruder motor current on K1 printers	2024/06/17 09:42	jattie

K1 Motor Current reduction

The Creality K1 printers¹⁾ are overheating the extruder motors because the motor current are by default too high causing excessive motor heat during long print jobs.

In order to access the extruder motor current parameters you need to have a rooted setup. The most comprehensive easy to use method to get this set up can be found here: [enable root access](#)



In the Klipper environment select the config menu {} on the left and select the printer .cfg file.



Edit line 205 to look like line 206. **Select save and restart.**

The extruder motor current is now reduced and the motor should run substantially cooler.

1)

<https://3dprintbeginner.com/creality-k1-review-corexy-for-tinkerers/>

From:
<http://www.3dfaq.net/> - 3D Printing Wiki

Permanent link:
http://www.3dfaq.net/05_creality_k1/01_reduce_extruder_current?rev=1728994667

Last update: **2024/10/15 12:17**

